

# PRP-300

## Thermal Receipt Printer

### Instruction Manual



Save the user manual for future reference.



# Table of Contents

<b>A. IMPORTANT SAFETY NOTIFICATION .....</b>	<b>1</b>
<b>B. PRODUCT OVERVIEW.....</b>	<b>3</b>
Main Features.....	3
Packing.....	4
Specification .....	5
Part Description .....	7
DIP Switch Configuration.....	13
<b>C. INSTALLING YOUR PRINTER .....</b>	<b>15</b>
Connecting Your Printer.....	15
Install/Replace the Paper Roll.....	16
Printer Configuration.....	23
<b>D. APPENDIX.....</b>	<b>29</b>
1. Cutter Maintenance.....	29
2. RS-232 Pin Assignment .....	31
3. RJ-11 Pin Assignment.....	32
4. Self Test .....	33
5. Virtual Serial Port Installation (for USB Connection Only) .....	34
6. Ethernet Connection and Configuration .....	43
7. Code Page Setup.....	60



## A. Important Safety Notification

- Read the instruction manual carefully before use. Save the manual in the near location for further reference.
- Use only parts or accessories, especially power adapter, recommended by the manufacturer; unapproved parts may be hazardous and cause injuries to the product or human.

### **WARNING:**

IF ANY FUNCTIONAL PROBLEMS OR DEFECTS OCCUR WHICH ARE ATTRIBUTABLE TO IMPROPER USE OF THE PRODUCT SHALL VOID THE WARRANTY.

- Refer servicing to qualified personnel only.
- Do not attempt to repair or disassemble the product on your own. Opening or removing cover can expose you to dangerous voltage or other hazards.
- Before plugging the power cord into the AC inlet of the power supply unit, make sure that the voltage applied to the power outlet is within the specified range (100V ~240V). Improper power source voltage range will cause damage to the power supply unit.
- Power off the product and remove the power adapter while cleaning the system.
- Before powering on the product, make sure all the connectors, cables are firmly installed.

## Important Safety Notification

- Do not expose the product to rain or moisture, such as a bathtub, a washbowl, a kitchen sink, a laundry tub, and a swimming pool.
- Do not expose the machine under direct sunlight, and keep it away from any heat source.
- Do not place the product on an unstable location, stand or table. If the machine falls, it may injure a person or cause serious damage to the appliance.
- Do not allow anything to rest on the power cord. Do not locate the product where people may walk on the cord.
- Do not make the power outlet and extension cords overload. Overload can result in fire or electric shock.
- If any of the following situations occurs, unplug the product from the power outlet immediately and consult with a qualified service person:
  1. The power cord or plug is damaged or frayed.
  2. Liquid is spilled into the system.
  3. The product is dropped and damaged.
- Use a soft cloth to clean the product when it is dirty. In case the dirt is hard to remove, use a mild detergent and wipe the product gently.  
Turn OFF and unplug the product before cleaning.
- When the product is not in use, clean and stores it with care.

## B. Product Overview




### Main Features

- Compact and Stylish Design
- Paper Auto-Cutter
- Multi-I/O Interface  
(Serial +Ethernet +USB)
- Cash drawer connection port (RJ-11)
- Compatible with ESC/POS print commands set
- Various Drivers support
- User friendly, drop-and-print paper installation, simple paper jam elimination
- Multiple Language fonts selectable
- DHCP Client support (Ethernet Connection)

## Packing



**Printer Unit**




**Power Adaptor**



**\*Power Cord**



**\*\*Printer Cable**



**Paper Roll**



**Paper Roll Holder**



**Paper Width Guide**



**Manual**



**Utility CD**

\* Power Cord is selectable depending on the types of electrical plug.

\*\* Printer cable is selectable depending on the interface required (RS-232, USB, RJ-45 or Parallel).

Please refer to the nearest local representatives for further information.

## Specification


General		
<b>Print Method</b>		Thermal line printing
<b>Print Speed</b>		250mm/sec
<b>Print Life</b>		100 Km
<b>Print Font</b>	<b>(ASCII Mode)</b>	ANK Font. Font A: 12 x 24 dots, Font B: 9 x 17 dots
	<b>Graphic Font)</b>	Chinese Character: 24 x 24 dots
<b>Print Resolution</b>		576 dots/line or 512 dots/line
<b>Print Font Character Support *</b>		International Font, Big 5 Chinese, GB Chinese, Japanese, Korean selectable
<b>Character Per Line</b>		48 (Font A) / 64(Font B)
<b>Effective Print Width</b>		72mm
<b>Paper Width</b>		79.5mm± 0.5mm
<b>Paper Roll Diameter</b>		≤83mm
<b>Paper Thickness</b>		0.06~0.08mm
<b>Driver</b>		Win 9X/Win ME/Win 2000/ Win 2003/Win NT/Win XP/ Win Vista/Win 7, Win 8 compatible with EPSON and SAMSUNG
<b>Print Command</b>		ESC/POS print commands set
<b>Buffer</b>	<b>Receipt</b>	128K bytes
	<b>User-Defined</b>	128K bytes
	<b>NV Flash</b>	256K bytes

<b>Interface</b>	
<b>I/O Interface</b>	Multi I/O Interface (Serial +Ethernet +USB)
<b>Cash Drawer</b>	DC 24V/1A, 6-Wire RJ-11
<b>Notification</b>	
<b>Indicator</b>	Audio and LED Indicators
<b>Auto Cutter</b>	Partial
<b>Paper End Notice</b>	Yes
<b>Over-Heat Halt-on Protection</b>	<b>Yes</b>
<b>Others</b>	
<b>Power Input</b>	24VDC/2.5A (External Adapter: 100~240VAC 50/60Hz)
<b>Color</b>	Black / White
<b>Compliance</b>	FCC / CE / WEEE / RoHS
<b>Weight</b>	1200g ( without cable )
<b>Dimension (mm)</b>	174(L) x 144(W) x 124(H)
<b>Operating Temperature</b>	0°C~45°C
<b>Operating Humidity</b>	10% ~ 80% RH, non-condensing
<b>Storage Temperature</b>	-10°C~ 60°C
<b>Storage Humidity</b>	10% ~ 90% RH non-condensing


\* All specifications are subject to change without prior notice.

# Part Description


## Product Views




**Top View**




**Side View**



**Front View**




**Bottom View**





**Rear View (Serial/USB)**

## Dimensions



## Control buttons & Indicators



## Control Buttons

### Paper Feed:

This function is to advance the paper.

Press the key and the paper advances by a single line.

Press and hold the key for over 3 seconds and the paper advances by multiple lines.


### Cover Release Button:

Push the button to the right to open the printer cover.


## Indicator Status

Indicator	Status	Description
Power		Power Off
		Power On
Error		Printer Error (Out of paper, Printer head over heat, or paper cutter error)
Paper		Out of paper * The Error Indicator is lit as well

# I/O Ports & Configuration DIP Switches




Rear View



## Note:

When plug the cables to the Printer, detach the I/O Port Bracket beforehand so as to secure connectors easily. Remember to re-install the I/O Port Bracket to the printer as the connectors are properly secured.

## Multi-I/O Ports



**USB**



**RS-232**



**RJ-45**



**RJ-11**



**PWR**



**\*Printer Cable**


**Cash  
Drawer**

**Power  
Adaptor**

## DIP Switch Configuration

To change the setting of the printer manually:

1. Turn off the printer.
2. Remove the protective cover of the DIP Switches.
3. Adjust the DIP switches to configure the printer.



Protective Cover

## DIP Switch Setting



DIP	Function	ON	OFF
1	Paper Cutter	No	Yes*
2	Audio Alarm	Yes *	No
3	Print Density	Dark	Light *
4	Two-byte Character Code	*No	Yes
5	Character Per Line	42	48 *
6	Cutter with Cash Drawer	Yes	No *
7 & 8	Baud Rate Setting	---	OFF*

The “\*” mark indicates the default value of each setting.

## Baud Rate Setting (DIP 7, DIP 8)



**19200**  
**(\*Default)**



9600



115200




38400

## C. Installing your Printer

### Connecting Your Printer


Please check the printer and the supplied accessories before Installation. It's recommended to read the entire instruction manual prior to the installation.




1. Place the printer on the designate location.
2. Detach the I/O Port Bracket.  
Plug the connector of Power Adaptor to the printer.
3. Use the supplied Printer Cable (RS-232, USB or RJ-45) and connect to the Host PC.
4. Plug the Power Cord to the Power Adaptor and then plug to the power outlet.
5. If there is a Cash Drawer to be connected, connect the RJ-11 cable to the printer.
6. Re-install the I/O Port Bracket.

## Install/Replace the Paper Roll


1. Pull the Cover Release Button to open the Cover.




2. Pass the Paper Roll Holder through the Receipt Paper Roll.



3. Roll out and install the Paper Roll with Holder into the Printer. (with the edges of the paper roll holder fitted onto the holder slots)




4. Replace the Cover and tear out the paper.



## Install the Paper Width Guide

When using a paper roll in smaller width, install the Paper Width Guide first, and then install the paper roll with holder.

### Paper Roll & Holder



## Installing the Driver of the Printer

Before installing the driver of your printer, make sure the printer is properly connected to the host PC.

Place the supplied Utility CD into the CD-ROM drive. Browse the CD and open the folder “Receipt Printer” to install the required software.



Catalog



Manual



OPOS



Receipt Printer






Utilities

### **Note: For USB Interface Installation**

Please refer to “**D Appendix**” (page 34) and install the Virtual COM driver prior to the Installation of Printer Driver.

To install the driver of the printer:

1. Select the folder “Driver for Windows”.




2. Select the subfolder to access the driver suitable for the operating system.  
(For example: select “Win2000\_XP\_Vista\_7\_x32&x64” for Windows XP version).



3. Double click the icon “PRPDRVEN.EXE” to initiate the installation.



4. Click “Next” to continue.



5. Select the Operating System.


(For example: select “Windows XP” for Windows XP version). Click “Next” to continue.



## Printer Configuration

This menu allows user to configure the printer according to the model number.

Please refer to the steps below to complete the configuration.




The screenshot shows a Windows-style dialog box titled "Detail Setting (x86/x64)". It contains the following elements:

- An "Install Module" dropdown menu with "PRP-058II Series" selected.
- A "Printer Setting" section containing:
  - A checked checkbox labeled "Set Default Printer".
  - A "Printer Name" text box containing "PRP-058II Series".
- Three buttons at the bottom: "< Back", "Next >", and "Exit".
- A footer note: "This Driver is suitable for Windows x86 and x64 OS."

## 1. Select Module Number:


Select the proper Printer Model Number



## 2. **Default Printer Setting:**


To set the printer as the default printer, click the checkbox to confirm.

Click “Next” to continue.



### 3. Printer Interface Setting:

- Select the communication interface (COM port number or LPT port number).
- Click “Install” to complete the installation.



### 4. Configuration Completed.


- Click “Finish” to exit the menu.



## 5. Port Setting:


Remember to access the properties of your printer (Start>>Printers and Faxes>> and double-click the icon to enter).

Make sure the port of printer is correctly configured.



Access sub menu “Ports”, and click to select the correct port for your printer.

Click “OK” to exit.



## **D. Appendix**


### **1. Cutter Maintenance**

In general, the printer will initial and reset the cutter when turn on the power. To reset the cutter back to the initial position:

1. Turn off the printer.
2. Turn on the printer and the printer will initial and reset the cutter.

User can manually reset the cutter back to initial position (as images illustrated):

1. Push the Cover Release Button to open the Cover. Examine and remove the paper dust from the printer by using a soft brush.
2. Push the Front Cover and remove it from the printer.
3. There is an Adjustment Gear in the cutter. Turn the Adjustment Gear to move the cutter back to the position.




**Note:**

Do not remove the protective cover with force or it may damage the cutter or printer head.

**Warning:**

Beware of the Cutting Edge of the cutter module during maintenance in order to avoid injury to the person near the printer.

## 2. RS-232 Pin Assignment



Pin	Signal	Description
1	N.C.	
2	TXD	XON/XOF Handshake (Control codes transmission).
3	RXD	Data transmission (the printer receives data from the HOST)
4	N.C.	
5	GND	Ground
6	DTR	Printer Status
7	N.C.	
8	RTS.	Printer Status
9	N.C.	

### 3. RJ-11 Pin Assignment


<b>Pin</b>	<b>Signal</b>	<b>Signal Direction</b>	<b>Description</b>
1	Ground	---	Frame Ground
2	Cash Drawer Kick Out Signal 1	Output	
3	Cash Drawer Status	Input	Open/Close
4	+VDC 24v	---	
5	Cash Drawer Kick Out Signal 2	Output	
6	GND	---	Signal Ground

## 4. Self Test

This function allows user to perform self-test and print out the settings of the printer unit:


1. Turn off the printer.
2. Press and hold the Paper Feed Button.
3. Turn on the Power Switch of the printer.
4. Release the Paper Feed Button.

The Indicators would blink and then the printer starts printing out the self test data.



## 5. Virtual Serial Port Installation (for USB Connection Only)


When connect the receipt printer to the computer with USB cable, turn on the computer and the system will found a new hardware automatically and then initiate the Found New Hardware Wizard automatically (as image below illustrated):



1. Found New Hardware Wizard is initiated; click “Install from a specific location (Advanced)” and then click “Next” to continue.



2. To specify the location of driver, click “include this location in the search and “Browse” the specified folder manually.



3. Browse the subfolder of the path:” \\Receipt Printer\PRP\_Printer\_USB\_COM\_Driver” (x86 for Windows XP 32 bit version).

Click “OK” to continue.



Driver for Windows



inf Driver for Windows




PRP Printer USB COM Driver




Tools




4. As the location of the driver is specified.  
Click “Next” to continue.



5. Start Notification. Click “Continue Anyway” to continue.




6. The wizard is installing the driver.




7. The driver of Virtual Serial Port is successfully installed. Click “Finish” to exit.

**Note: Reboot the HOST PC**


It's recommended to reboot the HOST PC and proceed to the next step.



8. The Virtual COM port activates automatically when the printer is switched on.  
You can Access  
“My Computer>>Proprieties>>Hardware>>Device Manager>> Ports (COM & LPT)” and see the Virtual COM Port Number.



When turn on the printer, the Virtual COM activates automatically (Virtual Serial Port).



## 6. Ethernet Connection and Configuration

When connecting the printer to the Host PC, you can:

### 1. **Direct Cable Connection:**


Use the supplied Ethernet crossover cable to create a direct cable connection to your Host PC.

#### **Note:**

Be sure to assign the IP address of the Host PC under the same subnet as your Printer

e.g.: Printer: **192.168.123.100**

Host: **192.168.123.xxx**



**Assign the IP address of the Host PC  
(Direct Cable Connection)**

2. **DHCP Client Connection:**

Connect the printer to the Local Net work (via HUB) with a standard Ethernet Cable.

The DHCP server will assign an IP address to the printer.

Be sure to configure the printer to the **DHCP Client Mode** before install the printer to the Local Network.

**Note:**

It's recommended to consult the MIS personnel relating to the information about the Local Network and IP address assignment.

- **Acquire the IP address of the Printer**

You can perform Self-Test of the printer and acquire the IP address of the printer.

- **Fixed IP Setting (Default)**

If a fixed IP address is assigned to the printer, perform the self-test and the printer will print out the data.

Protocols:	TCP/IP (A1)
Mac address:	X-XXX-XXX-XX
IP address:	192.168.123.100
Netmask:	255.255.255.0
Gateway:	192.168.1.1
DHCP:	Disabled

**Print out the Self-test data**

**Note:**


The default IP address is 192.168.123.100

## ■ DHCP Client Mode

If the printer is set to DHCP Client mode, the DHCP server will assigned an IP address to the printer when connecting to the local network.

Perform the self-test and the printer will print out the test data; then the printer will stand by to receive the IP address from the DHCP server.

As the IP address is assigned to the printer and configuration is completed, the printer will print out the assign IP address.



### **Note:**

The printer will be set to the default IP address (192.168.123.100) when there is not any IP address assigned to the printer (DHCP timeout is 90 seconds).

## ● IP Reconfiguration

You can open the web-browser and type the IP address to access the **Ethernet WebConfig** utility.


### Note:

When first re-configuring the IP address of the printer, you may need to use the supplied Ethernet crossover cable to establish a direct cable connection to your Host PC and start IP re-configuration.

## ■ Interface Status

This menu displays the current configuration data of the printer. Click “Refresh” to acquire the newest data.

### Ethernet WebConfig Version 1.00



The screenshot shows the Ethernet WebConfig interface. At the top, there is a title bar that says "Ethernet WebConfig Version 1.00". Below this is a navigation menu on the left with three items: "Interface Status" (which is selected and underlined), "Printer Status", and "Configure Interface". At the bottom of the navigation menu is a "Reboot" button. The main content area is titled "Interface Status" and includes a sub-header "View the current status of the interface module." Below this, there is a table of configuration data:


Mac Address	0-108-148-167-101-159
IP Address	192.168.123.100
Subnet Mask	255.255.255.0
Gate Way	192.168.123.1
DHCP	Disabled
DHCP Timeout	90

At the bottom right of the configuration data is a "Refresh" button.

## ■ Printer Status

This menu displays the printer status and can perform print test.

### Ethernet WebConfig Version 1.00



The screenshot shows the Ethernet WebConfig interface. At the top, there is a title bar for "Ethernet WebConfig Version 1.00". Below it is a navigation menu with three items: "Interface Status", "Printer Status" (which is highlighted), and "Configure Interface". At the bottom of the navigation menu is a "Reboot" button. The main content area is titled "Printer Status" with a subtitle "Check the status of the connected printer." Below this, there is a list of printer status indicators:

Cover Is Open	No
Cutter Error	No
Paper End	No
Paper Near End	No
Printer Off-Line	No

At the bottom of the main content area, there are two buttons: "Print Test Page" and "Refresh".

## ■ Configure Interface

This menu can change the IP address of the printer.

To change the IP address.

1. Type the new IP address and click “Save” button.  
User can set to “DHCP Client” to enable the DHCP mode.

### **Note: DHCP Timeout**

The DHCP time out is configurable from 14 sec to 90 sec.

2. Click “Reboot” button to re-initiate the printer.

## Ethernet WebConfig Version 1.00

The screenshot displays the 'Configure Interface' web page. On the left is a navigation menu with links for 'Interface Status', 'Printer Status', and 'Configure Interface'. The main content area is titled 'Configure Interface' and 'Settings for the Ethernet Interface'. It features two radio buttons for 'IP Address': 'DHCP Client' (unselected) and 'Fixed IP Address' (selected). Below these are input fields for 'DHCP Timeout (s)' (set to 90), 'Device IP Address' (192.168.123.100), 'Subnet Mask' (255.255.255.0), and 'Gateway Address' (192.168.123.1). At the bottom are 'Restore Default', 'Save', and 'Exit' buttons. A red dashed box highlights the DHCP Client section and the Fixed IP Address section.

Interface Status	<b>Configure Interface</b> Settings for the Ethernet Interface
Printer Status	
Configure Interface	

IP Address:  DHCP Client:  
DHCP Timeout (s)

Fixed IP Address:  
Device IP Address      
Subnet Mask      
Gateway Address

### Note: Restore Default Configuration

You can click “Restore Default” button to retrieve the factory IP configuration data of the printer.

(IP Address: 192.168.123.100)

Fixed IP Address:

Device IP Address	192	.168	.XXX	.XXX
Subnet Mask	255	.255	.255	.0
Gateway Address	192	.168	.123	.1


**Restore Default**   Save   Exit

## ■ Reboot

This function can re-initiate the printer and apply the new configuration.

1. Click the “Reboot” button to re-initiate the printer.  
Click “OK” to proceed.

### Ethernet WebConfig Version 1.00



The screenshot shows the 'Configure Interface' page of the Ethernet WebConfig. The page title is 'Configure Interface' and the subtitle is 'Settings for the Ethernet Interface'. On the left sidebar, there are three menu items: 'Interface Status', 'Printer Status', and 'Configure Interface'. The 'Reboot' button is highlighted with a red rectangle. The main content area shows the IP Address configuration options: 'DHCP Client' (selected) and 'Fixed IP Address' (deselected). The DHCP Client section has a 'DHCP Timeout (s)' field with the value '90'. The Fixed IP Address section has three rows of input fields: 'Device IP Address' (192, 168, 123, 100), 'Subnet Mask' (255, 255, 255, 0), and 'Gateway Address' (192, 168, 123, 1). At the bottom of the configuration area, there are three buttons: 'Restore Default', 'Save', and 'Exit'.



2. The Printer is initiating.

### Ethernet WebConfig Version 1.00

The screenshot shows the Ethernet WebConfig interface. On the left is a blue sidebar with links: [Interface Status](#), [Printer Status](#), and [Configure Interface](#). At the bottom of the sidebar is a [Reboot](#) button. The main content area has a title **System Message** and a message box containing the text: "Please Wait for printer to reboot! But if you change the IP address, Enter the new address to the address bar after the printer reboot."

3. Printer is initiated successfully.

### Ethernet WebConfig Version 1.00

The screenshot shows the Ethernet WebConfig interface after a successful reset. The sidebar on the left is identical to the previous screenshot. The main content area has a title **System Message** and a message box containing the text: "Reset is complete! Printer have restart complete now." Below the message is a [Go Home](#) link.


#### Note:

Be sure to access the printer using the new IP address after reboot the printer.


## ● Setup the TCP/IP Printer Port

After the IP address of the printer is re-configured, you can install the printer driver and setup the printer port of your printer.


1. Access “Start>>Printer and Faxes>> Printer properties.



2. Access submenu “Port” and click “Add Port”.




3. Select “Standard TCP/IP Port” and click “New Port.” and proceed.



4. Add TCP/IP Print Port Wizard initiated.  
Click “Next” to continue.



5. Enter the IP address of the Printer then proceed.



## 6. Additional Port Information.

Select “Custom” and click “Setting” to continue.



## 7. Port Setting.

Please examine the IP address should be the same to the Printer.

Select the protocol “Raw” and click “OK” to continue.

**Configure Standard TCP/IP Port Monitor**

Port Settings

Port Name: IP\_192.168.123.100

Printer Name or IP Address: 192.168.123.100

Protocol

Raw  LPR

Raw Settings

Port Number: 9100

LPR Settings

Queue Name:

LPR Byte Counting Enabled

SNMP Status Enabled

Community Name: public


SNMP Device Index: 1

OK Cancel

8. Click “Finish” to complete.



9. You can exit the setting menu and open the printer properties to perform print test. Click “Print Test Page” to perform the test.



## 7. Code Page Setup

Place the supplied Utility CD into the CD-ROM drive.

1. Browse the CD and open the folder “Receipt Printer” to install the required software.



Catalog



Manual



OPOS



Receipt Printer



Utilities

2. Open the folder “Tools” to access the utility software.



Driver for Windows



inf Driver for Windows



PRP\_Printer\_USB\_COM\_Driver



Tools

3. Click the folder “SetCodePage” to access the software



4. Double click the icon “Setup.EXE” to initial installation.  
Follow the instructions to install the utility.



## ● Code Page Setup Utility

This utility can help user to setup the code page of the printer.

### Note: Before Setup

It may need to re-configure the printer prior to the codepage setup (e.g.: DIP switch).


It's recommended to consult the technical personnel relating to the information about the code page and application.

### ■ Interface

User can establish communication with printer via this menu. Select the proper submenu by the connection type of the printer.


#### For Serial COM Port:

Select the proper COM port and baud rate to establish communication.




## For Parallel LPT Port:

Select LPT1 as the printer port to establish communication.



## For Ethernet (TCP/IP):


Enter the IP address of the printer to establish the communication.



## ■ Select Page Code

To select the codepage desired:

1. Make sure to the DIP switch 4 of the printer is set **ON** (please refer to DIP Switch Configuration for further information).
2. Go to the scroll menu and select the preset codepage desired.  
User can enter the codepage number into the field manually. (Please refer to the printed Self-Test page for the code number support).
3. Click “Set” button to confirm the setting.



## 4. Re-initiate the Printer:

Be sure to **Turn-Off and Turn-On** the printer again to initiate the printer with new codepage setting.  
(User can perform the self-test again to exam the new codepage setting)



